



BATTISTINIS CUSTOM CYCLES

1109 LANGTON DRIVE
SAN RAMON, CA 94582
925.270.4211 TECH LINE
WWW.BATTISTINISUSA.COM

**06-820
B2 SERIES
CHROME BILLET
RIDER FLOORBOARDS**

**06-822
B2 SERIES
BLACK ANODIZED BILLET
RIDER FLOORBOARDS**

BILL OF MATERIALS

Quantity	Part
1	Floorboard, left, chrome or black anodized
1	Floorboard, right, chrome or black anodized
4	Floorboard mount, front, black
4	Floorboard mount, rear, black
16	$\frac{1}{4}$ -.28 x $\frac{7}{8}$ " socket head cap screw
48	Rubber insert



BASIC TOOLS



**EASY:
15 minutes
to install
(approx.)**



MAINTENANCE: To keep your new floorboards looking their best, apply a high-quality chrome polish to them every time you detail your motorcycle.

WARNING: Your safety depends on the correct installation of this kit. Use appropriate service manual procedures. If the procedures are not within your capability or you do not have the correct tools, have a trained mechanic/technician install this part for you. Improper installation of this part could result in injury or death.

STEP 1: Following the specifications listed in the appropriate service manual for your year and model of motorcycle, remove the existing floorboards. The OEM mounting hardware will be re-used in the installation of the Battistinis floorboards, so keep it with the motorcycle during the installation.



STEP 2: The Battistinis floorboards install using the OEM shoulder bolts and locknuts. Following the specifications listed in the appropriate service manual for your year and model of motorcycle, install the Battistinis billet floorboards. Verify the torque on all mounting hardware, and you are now ready to enjoy your new Battistinis billet floorboards.

