



BATTISTINIS CUSTOM CYCLES

1109 LANGTON DRIVE
SAN RAMON, CA 94582
925.270.4211 TECH LINE
WWW.BATTISTINISUSA.COM

BILLET GRIPS FOR METRIC CRUISERS

50-118 BLACK ANODIZED
50-119 CHROME

BILL OF MATERIALS

Quantity	Part
1	Billet grip, left, chrome or black anodized
1	Billet grip, right, chrome or black anodized
3	M4 x 4mm set screw, stainless steel
1	Handlebar end plug, black plastic



 **MAINTENANCE:** To keep your new grips looking their best, apply a high-quality chrome polish to them (for chrome grips) or clean them thoroughly (for black grips) every time you detail your motorcycle.

WARNING: Your safety depends on the correct installation of this kit. Use appropriate service manual procedures. If the procedures are not within your capability or you do not have the correct tools, have a trained mechanic/technician install this part for you. Improper installation of this part could result in injury or death.

STEP 1: For kits that include a black plastic handlebar end plug, it is necessary to install this plug in the end of the handlebar on the throttle side (inset). The throttle-side grip slides over the handlebar as shown. Install the throttle cables onto the grip as per the procedure outlined in the appropriate service manual for your year and model of motorcycle. Check for proper throttle operation before riding your motorcycle.



STEP 2: Now install the left-side grip. Remove the existing grip and clean the handlebar end if necessary. The new left-side grip is held in place with three stainless steel set screws. Use a drop of blue Loctite 242 on either the set screw threads or in each of the threaded holes in the grip. Slide the grip up the handlebar and position it to your preference. Tighten each of the three set screws a little at a time to ensure that they are all tightened uniformly, as shown.

