


BATTISTINIS CUSTOM CYCLES

1109 LANGTON DRIVE
SAN RAMON, CA 94582
925.270.4211 TECH LINE
WWW.BATTISTINISUSA.COM

B2 SERIES CHROME BILLET & BLACK ANODIZED PASSENGER FLOORBOARDS



 **MAINTENANCE:** To keep your new floorboards looking their best, apply a high-quality chrome polish or cleaner to them every time you detail your motorcycle.

BILL OF MATERIALS

Quantity	Part
1	Floorboard, left
1	Floorboard, right
4	6-32 x 1/4" set screw, stainless steel
26	Rubber insert

WARNING: Your safety depends on the correct installation of this kit. Use appropriate service manual procedures. If the procedures are not within your capability or you do not have the correct tools, have a trained mechanic/technician install this part for you. Improper installation of this part could result in injury or death.

STEP 1: Following the specifications listed in the appropriate service manual for your year and model of motorcycle, remove the existing passenger floorboards. The OEM pivot pins (arrows) will be re-used in the installation of the Battistinis passenger floorboards, so keep them with the motorcycle during the installation.



STEP 2: Following the specifications listed in the appropriate service manual for your year and model of motorcycle, install your new Battistinis chrome billet passenger floorboards. There are two 6-32 set screws in each floorboard (arrows, inset) along the pivot bore that must be tightened securely to the pivot shaft. Following this, you are now ready to enjoy your Battistinis chrome billet passenger floorboards.

