



BATTISTINIS CUSTOM CYCLES

1109 LANGTON DRIVE
SAN RAMON, CA 94582
925.270.4211 TECH LINE
WWW.BATTISTINISUSA.COM

CHROME BILLET SHIFT PEG & BLACK ANODIZED BILLET SHIFT PEG



BASIC TOOLS



EASY:
15 minutes
to install
(approx.)

BILL OF MATERIALS

Quantity	Part
2	Chrome or black anodized billet shift peg
1	5/16 -18" set screw, black oxide



MAINTENANCE: To keep your new shift peg looking its best, apply a high-quality chrome polish to it (for chrome pegs) or clean it thoroughly (for black pegs) every time you detail your motorcycle.

WARNING: Your safety depends on the correct installation of this kit. Use appropriate service manual procedures. If the procedures are not within your capability or you do not have the correct tools, have a trained mechanic/technician install this part for you. Improper installation of this part could result in injury or death.

STEP 1: To begin, remove the existing shift peg, as per the specifications listed in the appropriate service manual for your year and model of motorcycle. Inspect the condition of all shift linkage at this time and perform any maintenance if necessary.



STEP 2: Install the new chrome billet shift peg as per the specifications listed in the appropriate service manual for your year and model of motorcycle. Slide a short length of fuel line over the shank of a large screwdriver and place the tool through the holes in the shifter peg and tighten the footpeg against the set screw as shown. You are now ready to enjoy your new Battistinis billet shift peg. Enjoy!

